



Flux



Recommended Tools




Adjustable Peninsula Desk Assembly



Hardware Used



Package Contents



Notice To Installers: Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.



Step 1

Position and Level Units

- Position adjustable desk panel base and credenza in desired location. The length of desk top will determine the spacing between panel base and credenza.
- Level units front-to-back and side-to-side by rotating adjustable glides.

Adjustable Peninsula Desk Assembly (continued)

TOP VIEW




Notice To Installers: Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.

Step 2

Attach Worksurface

Adjustable Peninsula Desk Assembly (continued)

- Carefully lower Desk Top Assembly into place




Fasten understructure to adjustment columns using eight (8) #6 X 12mm socket head bolts, four (4) per side.

Note: Hand tighten only. Do NOT secure firmly at this point.

Notice To Installers: Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.

Step 3
Connect Electrical Wiring


Adjustable Peninsula Desk Assembly
(continued)




Notice To Installers: Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.

Step 4
Secure Worksurface To
Adjustable Height Columns

Adjustable Peninsula Desk Assembly
(continued)



Raise worksurface for easier access to understructure




Using hex wrench, tighten all machine bolts firmly to the columns

Notice To Installers: Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.

Step 5
Attach Wire Manager
 (Optional)


Adjustable Peninsula Desk Assembly
 (continued)




Notice To Installers: Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.

Flux

Step 6
Route Power Cord
Through Wire Manager



Adjustable Peninsula Desk Assembly
(continued)





Notice To Installers: Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.

Flux

Step 7
Alternate Wire Manager Attachment
(Optional)

Adjustable Peninsula Desk Assembly
(continued)



Notice To Installers: Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.