


GENERAL PRODUCT

HOW TO ATTACH AND ASSEMBLE AN OPTIONAL CORNER MODESTY PANEL

Recommended Tools




Hardware Required



#8 x 7/8"
PHP Screws



#8 x 5/8"
PHP Screws



90° brackets



L-Bracket

Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.

Figure 1







Figure 2




1. On each modesty panel, align the two 90° brackets to that they are flush with the top edge and 4 inches inset from each end, then secure with #8 x 5/8" screws (Figure 1)
2. On each modest panel, align the two L-brackets so that they are 12 inches on either side from the center, the secure with #8 x 5/8" screws (Figure 2)
3. Gang the two modesties using an L-bracket and #8 x 5/8" screws. Modesty that covers the return side should be butted against the end of the main modesty (Figure 3 & 4)



GENERAL PRODUCT

HOW TO ATTACH AND ASSEMBLE AN OPTIONAL CORNER MODESTY PANEL

Figure 5



4. Inset the modesty the appropriate distance from the approach side of the desk. Secure to the top with #8 x 7/8" screws. Refer to Chart 1 for information on inset (Figure 4)




Chart 1

Modesty Location	
Surface Depth 'B'	Inset Distance 'C'
36 in	3 in
30 in	3 in
24 in	1-1/2 in

Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.