



# GENERAL PRODUCT

## INSTALLATION OF A WALL MOUNT TACKBOARD



1. Mark wall to align wall mounted cleats with those mounted to tackboard. Top cleat should be mounted 5-13/16" lower than the desired height of the tackboard.
2. Attach the provided cleats to the wall in accordance with local code (Figure 1)
3. Slide the tackboard with cleats down to engage all cleats (Figure 3)



NOTE: Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.

