

Kindera Replaceable Part - Arm Cap

Install Instructions

Tools Required

- #2 Phillips Head 
- Drill 

Hardware Included

- 4 - Flat Head Bolt 

Installation

1. Locate the four holes on the recliner arm and the four holes on the arm cap (Figure A).
2. Place the arm cap on top of the recliner arm frame and line up the holes (Figure B).
3. Make sure spring and paddle retainer doesn't move or fallout.
4. Using the drill, attach the arm cap to the top of the arm with the 4 flat head bolts. **DO NOT TIGHTEN BOLTS ALL THE WAY UNTIL ALL BOLTS ARE THREADED IN** (Figure C).
5. Once all bolts are threaded into the arm cap, tighten all bolts.
6. Finished (Figure D).

Figure A




Figure B




Figure C




Figure D

