

# Kindera Replaceable Part - Mid-Ottoman

## Install Instructions

### Tools Required

- # 2 Phillips Head 
- Drill 

### Hardware Included

1. 2 - Pan Head Screw 

### Installation

1. Lay the recliner on its back.
2. Locate the two holes on the mid-ottoman (Figure A).
3. Line up the holes on the mid-ottoman with the holes on the mid-ottoman bracket.
4. Using the drill, secure the mid-ottoman to the mid-ottoman bracket with the pan head screws provided (Detail A, Figure B).
5. Tighten all screws.
6. Connect the velcro from the mid-ottoman to the velcro on the bottom of the seat.
7. Flip the recliner back right side up (Figure C).

Figure A




Figure B




Figure C

