

Kindera Replaceable Part - Ottoman

Install Instructions

Tools Required

- # 2 Phillips Head 
- Drill 

Hardware Included

1. 4 - Pan Head Screw 

Installation

1. Lay the recliner on its back.
2. Locate the four holes on the ottoman (Figure A).
3. Line up the holes on the ottoman with the holes on the ottoman bracket (Detail A, Figure A).
4. Using the drill, secure the ottoman to the ottoman bracket with the pan head screws provided (Detail B, Figure B).
5. Tighten all screws.
6. Flip the recliner back right side up (Figure C).

Figure A




Figure B




Figure C

