



Recommended Tools



Phillips Screw Driver




Screw Gun Phillips Head Bits & Drill Bits

Hardware Used



#1/4-20 X 3/4" Flat Head Bolt

Linking Brackets




Use with the following:

Armless

Straight Arms Chairs

Multiple Seating to Bariatric Seating

*Does not work with Flared Arm Chairs
and not recommended for stools and
chairs with casters*


Step 1

Installing the bumpers pads

- remove the brackets, screws and bumper pads from the packing bag
- peel the paper from the back of the bumper pads, and place the pad on to the metal bracket as indicated in diagram 1

*These bumper pads protect armless chair
when they are stacked*

diagram 1



insert bracket
mount on right side
(seated position)

Step 2

Preparing the frame

- carefully remove the round bumper from the chair frame in the second hole from the front




diagram 2

Step 3

Attaching the bracket

- align the brackets with 2nd and 3rd holes on the underside of the seat for seat side rail, use the screws provided and attached the brackets

*It is recommend male bracket be placed right
side (seated position) for consistency*

Notice To Installers: Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.