


LOK

REMOVABLE MODESTY PANEL INSTALLATION

Recommended tools



#2 Phillips Head

Hardware enclosed



LAMINATE



ACRYLIC

NOTE: all screws provided must be installed for proper installation and compliance with product warranty.



LAMINATE




ACRYLIC

Lok tables are factory ready to receive a modesty panel. Laminate and frosted acrylic panels can be ordered to coordinate with the table length. **Removable** brackets allow for quick removal with a threaded knob when a modesty panel is not required. Brackets are enclosed in the modesty panel carton located in a hardware bag with **HARDWARE ENCLOSED** sticker and taped to the modesty panel.

- With assistance from another person, lift and rotate table to set on the floor.
(**NOTE:** support the modesty panel while rotating the table to set on the floor to avoid damaging the hinge magnet)

laminate modesty panel:

- Attach the leg of angle brackets without slot to the back of the laminate modesty panel into pre-drilled holes with two #8 x 5/8" screws.
- Position the modesty panel with attached bracket to underside of table top and align slot with insert in underside of top. Install threaded knobs into the inserts.



acrylic modesty panel:

- Attach the leg of angle brackets without slot to the back of the acrylic modesty panel into holes in panel with machine bolts provided into panel face trim covers.
- Position the modesty panel with attached bracket to underside of table top and align slot with insert in underside of top. Install threaded knobs into the inserts.

