



LOK

TILT/NEST BASE INSTALLATION

Recommended tools



Hardware enclosed



NOTE: all screws provided must be installed for proper installation and compliance with product warranty.



a. INLINE NEST



b. OFFSET NEST



c. CANTILEVER BASE

Lok tilt/nest mechanisms ship factory installed to the table top for quick installation. Leg to mechanism attachment screws will be located in a hardware bag with **HARDWARE ENCLOSED** sticker and taped to the leg attachment plate on the tilt mechanism.

- With the table top face down on a non-marring surface, remove the leg attachment hardware bag with 8 attachment screws from the tilt mechanism plate, position the bases as shown above.
 - a.** inline nesting tables (bases angle with widest position facing user side of table)
 - b.** offset nesting tables (bases are parallel with end of table)
 - c.** cantilever base (bases are installed with the long foot section facing user short to approach)
- Install screws provided in the hardware pack with a cordless power drill/driver with clutch setting to avoid over tightening the screws. Screws are provide with a blue Lock-tite patch to prevent screws from loosening with use of the tables.