



Package Contents





Privacy Screen




**Step 1****Locate Bolt Slots on Inside of Chair**

- Carefully lay unit over on it's side.
- Pull open bottom cover flap and locate the upper and lower slots on inside back cavity.

Pull open bottom cover for access to inside back cavity

**Step 2****Insert Knob Bolts from Inside of Chair**


- Insert all 4 knob bolts into slots as shown:




Notice To Installers: Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.

Step 3**Attach Privacy Screen**

- Align top bolts with corresponding inserts on privacy screen, thread loosely. **DO NOT TIGHTEN.**
- Align lower bolts with corresponding inserts on privacy screen and begin threading.
- Once all four bolts have been threaded into inserts, tighten all down firmly.

**Privacy Screen
(continued)****Step 4****Measure Privacy Screen for Straightness**

- Measure for privacy screen to be straight and square with chair, adjust accordingly.
- Reapply bottom cover.
- Carefully set chair upright and inspect overall



Notice To Installers: Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.