



Metal Leg Installation

Install Instructions

Tools Required

- #2 Phillips Head 
- 1/8" Drill Bit (Optional)
- Drill 

Hardware Included

- 24 - #10 x 1 1/4" Truss Head Screw

Installation

Note: Due to the product weight, it is recommended two or more people help with the installation of the chair.

Note: All screws provided must be installed for proper installation and compliance with product warranty.

1. Lay out protective floor covering (cardboard, blanket, etc.)
2. Open box and remove objects from box.
3. Turn unit so the back is on the ground and the bottom of the unit is accessible.
4. Identify the six hole pattern located near each corner. (See Figure A)
5. (Optional) Holes can be predrilled if desired to assist in assembly. Use 1/8" drill bit.
6. Secure each leg to the chair frame using all six of the screws provided. (Figure B)
7. Repeat for each leg.
8. Set chair upright on legs. (Figure C)

Figure A




Figure B




Figure C

