



# Wood Leg Assembly

## Install Instructions

### Tools Required

- #2 Phillips Head 
- 1/8" Drill Bit (Optional)
- Drill 

### Hardware Included

- 16 - #10 x 1 1/4" Truss Head Screws

### Installation

Note: Due to the product weight, it is recommended two or more people help with the installation of the chair.

Note: All screws provided must be installed for proper installation and compliance with product warranty.

1. Lay out protective floor covering (cardboard, blanket, etc.)
2. Open box and remove objects from box.
3. Turn unit so the back in on the ground and the bottom of the unit is accessible.
4. Identify the four hole pattern located near each corner. (See Figure A)
5. (Optional) Holes can be predrilled if desired to assist in assembly. Use 1/8" drill bit.
6. There is a large hole at the center of the pattern, under the dust cover, that allows clearance for the lag bolt.
7. Secure each leg to the chair frame using all four of the screws provided. (Figure B)
8. Repeat for each leg.
9. Set chair upright on legs. (Figure C)

Figure A




Figure B




Figure C

