

Replaceable Part - Foot Rest

Install Instructions

Tools Required

- #2 Phillips Head 
- Drill 

Hardware Included

- 4 - Flat Head Screw 

Installation

1. Lay chair frame on back, so bottom of unit is accessible.
2. Locate holes in foot rest and in bottom of chair frame (Figure A).
3. Line up holes on foot rest with holes on bottom of chair frame.
4. Ensure the curve of the foot rest is facing the front of the chair.
5. Using the drill, secure the foot rest to the chair frame with the screws provided (Figure B).
6. Tighten screws to ensure they are secure.
7. Turn chair so it is upright (Figure C).

Figure A




Figure B




Figure C

