

# Tackboard Wall Mount — VSBxx22WT

## Install Instructions

### Recommended Tools

- Knife
- Tape Measure
- Level
- Stud Finder
- Screw Driver

### Installation

Note: Due to the product weight, it is recommended two or more people help with the installation of the desk.

1. Identify the product's installation location. Then move and unpack box(es) near the final installation location.
2. Determine desired height from floor to top of tackboard (X).
3. To find height from floor to bottom of upper wall cleat, subtract ( $9\frac{1}{4}"$ ) from height determined in step 2. Locate studs in wall and use screws to hang upper wall cleat. Hang lower wall cleat ( $10\frac{7}{16}"$ ) lower than upper wall cleat.
4. Hang tackboard on wall cleats.

Figure 1

