FLUX OPEN PLAN

HOW TO ATTACH AN EDGE MOUNTED TACKBOARD PRIVACY SCREEN

Figure 1



1. Attach the tackboard to the brackets using ¼-20 x ½" screws provided (Figure 1)
2. Attach the bracket to the worksurface using the ¼-20 x ½" screws through the threaded inserts in the underside of the worksurface (Figure 2)

NOTE: Worksurface should be positioned as shown (Figure 3)

Recommended Tools



Hardware Needed



¼-20 x ½" PHP
Machine Screws



Figure 2

Figure 3



Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.