FLUX OPEN PLAN

HOW TO ATTACH A WIRE TROUGH

Recommended Tools

#2 Phillips Head

Hardware Required

¼-20 x ½" PHP
Machine Screws

Figure 2

¼-20 x ½""

Bottom view of wire trough

Figure 1

Top view of wire trough

1. **Attach the L-Brackets to the underside of the wire trough using ¼-20 x ½" machine screws and the pre-drilled holes near the end of the trough (Figure 1)**

2. **Attach the L-bracket to the panel using the screws provided. Screws will go into the L-Brackets against the panel (Figure 2)**

3. **Repeat for other side**