



Attaching Run-off Desk with End Panel to a Support Credenza




Credenza Type



Recommended Tools





Hardware Used



Step 1 Attaching the Flat Brackets

- Determine the location (from the plan) for the run-off desk. Make sure credenza is level and placed correct in the layout location.
- Evenly space out a bracket locations provided with run-off desk. The flat bracket should be centered half way between the bracket length.
recommended one brackets be located in front of the standard modesty panel.
- See diagram A for flat bracket spacing.
- Fasten the flat bracket to the credenza using the provided screws, #8 x 7/8".






Notice To Installers: Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.

Attaching Run-off Desk with End Panel to a Support Credenza *continued*

Step 3 Attaching Run-off Desk

- Lift the run-off desk in to place, using the bracket on the credenza as support.
- Measure the location and level the run-off desk.
- Lift the run-off desk in to place, align the holes and fasten the brackets to underside of the run-off desk with the provided screws, #8 x $\frac{7}{8}$ " as shown in the diagram.
- Fasten three 90° angle brackets at the corner of the modesty panel (see diagram B) in the interior of the unit to the wing end panel of the credenza and the top of the credenza by using the screw provided, #8 x $\frac{7}{8}$ " screws.



Notice To Installers: Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.