


# FLUX OPEN PLAN

## INSTALLATION OF A CENTER MOUNT STORAGE UNIT



Product




Figure 1

### Recommended Tools



5/32" Allen wrench

1. Loosen both set screws located on the bottom of the aluminum rail using the 5/32" Allen wrench (Figure 1)
2. Slide extrusions on the bottom of the storage units into the rail until the unit is centered (Figure 2 & 3)
3. Use the 5/32" Allen wrench to tighten the set screws against the unit until it is secure (Figure 4)
4. Insert main extrusion cap on each end of the aluminum rail (Figure 5)




Figure 5




Figure 2




Figure 3




Figure 4

Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.