



FLUX OPEN PLAN

HOW TO ATTACH A TOP SURFACE

Recommended Tools



Hardware Needed



1/4-20 x 1/2" PHP
Machine Screws



#10 x 7/8" PHP Screws

Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.




Figure 1

1. Assemble all end support frames, stretchers, and aluminum rail in accordance to their instruction sheets.
2. Lay top panel upside down on a nonmarring surface
3. Position and secure assembled framing upside down on surfaces so that it is flush on all sides using #10 x 7/8" screws (Figure 1)
4. If included, use the connecting plate to connect two tops together by securing it on the underside of the tops centered side to side and front to back as shown. Use #10 x 7/8" screws to screw into the top panels and 1/4-20 x 1/2" screws to go into the aluminum rail (Figure 2)




Figure 2




Figure 3