



FLUX OPEN PLAN

HOW TO ASSEMBLE A SINGLE SIDED INLINE BENCH SURFACE

Recommended Tools




Hardware Needed



1/4-20 x 1/2" PHP
Machine Screws



#10 x 7/8 PHP Screws



Gang the aluminum rail and the narrower top together using the flat bracket

- use #10 x 7/8 screws provided when screwing into the top and 1/4-20 x 1/2" machine screws to secure to rail
- Aluminum rail and top piece should be flush along the sides and against one another

Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.