


FLUX OPEN PLAN

HOW TO ATTACH LEGS TO AN END SUPPORT STORAGE CREDENZA

Recommended Tools



Hardware Needed



#8 x 5/8" PHP Screws

Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.

1. Lay credenza upside down on a nonmarring surface
2. Align the legs so that they are flush with the sides and back of the cabinet then secure using #8 x 5/8 screws (Figure 1 & 2)

