


## Assembling and Attaching Run-off Desk with End Leg/Post Frame to a Support Credenza



Installers: Two set of brackets are included with the run-off desk, flat brackets and stepped brackets. Credenza are offered with aprons or no aprons.

### Types of Credenzas





flush to top - use flat bracket



apron rail top - use stepped bracket

### Recommended Tools



### Hardware Used

#8 x 7/8" Wood Screws

1/4-20 x 3/4" Pan Head Screws

four (4) flat brackets included


Flat Bracket

four (4) step brackets included

Step Bracket

## Step 1 End Frame Assembly / Post Frame Assembly Installation

- Unpack the end leg assembly/post frame assembly along with hardware.
- Align the top support rail perpendicular to the end leg assembly/post frame assembly using the two 1/4-20 pan head bolts to secure the top.
- Flip worksurface top upside down and lay on a flat clean debris free pad.
- Place leg or post assembly onto the bottom side of the worksurface top.
- Align the leg or post assembly with the prebored holes on the top for the assembly.  
(tabs on Top Support Rail are not pre-bored)
- Fasten assembly to the bottom side using #8 x 7/8" pan head screws.



**Notice To Installers:** Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.

## Assembling and Attaching Run-off Desk with End Leg/Post Frame *continued*

### Step 2 FLAT - Attaching Brackets

- Determine the location (from the plan) of the of the run-off desk. Make sure credenza is level and placed correct as per layout location.
- Evenly space out bracket locations provided with run-off desk. The flat bracket should be centered half way between the bracket length.  
*recommended all brackets be used.*
- Fasten the flat bracket to the credenza using the provided screws, #8 x 7/8".




diagram show placement for a 28" wide run-off desk top.

### Step 2 STEP - Attaching Brackets

- Determine the location (from the plan) of the of the run-off desk. Make sure credenza is level and placed correct as per layout location.
- Evenly space out bracket locations provided with run-off desk. To avoid interference with the run-off desk support rail do not place any brackets in the center. The step bracket should be up tight against the apron rail as shown in the diagram.  
*recommended all brackets be used.*
- Fasten the step bracket to the credenza using the provided screws, #8 x 7/8".





diagram show placement for a 28" wide run-off desk top.

*note: make sure the brackets are level*

### Step 3 Attaching Run-off Desk (Flat or Step Styles)

- Lift the run-off desk in to place, using the bracket on the credenza as support.
- Measure the location and level the run-off desk.
- Lift the run-off desk in to place, align the holes and fasten the bracket to underside of the run-off desk with the provided screws, #8 x 7/8". as shown in the diagram.



**Notice To Installers:** Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.