





## Recommended Tools




## Adjustable U-Unit Assembly



## Hardware Used





## Package Contents



**Notice To Installers:** Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.

**Step 1****Position and Level all Units**

- Position adjustable desk panel base and adjustable return panel base in desired location. The length of desk will determine the spacing of the two bases.
- Level all units front-to-back and side-to-side by rotating adjustable glides.
- Units that share same worksurface are to be adjusted to same height. (Dim. "A")

**Adjustable U-Unit Assembly  
(continued)**

**Notice To Installers:** Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.

**Step 2****Attach Fixed Modesty Panel****Position and Level all Units**

- Position adjustable desk panel base and adjustable return panel base in desired location. The length of desk will determine the spacing of the two bases.

**Adjustable U-Unit Assembly  
(continued)**

- Align all four fastening brackets

- Engage interlocking bracket components and lower panel for tight secure fit



- Check that unit is level front to back and side to side; adjusting leveling guides according

**Notice To Installers:** Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.

### Step 3

#### Attach Worksurfaces

### Adjustable U-Unit Assembly (continued)




**Notice To Installers:** Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.

## Step 4

### Connect Electrical Wiring

- Carefully lower Desk Top Assembly into place

## Adjustable U-Unit Assembly (continued)




**Notice To Installers:** Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.

**Step 5**

Secure Worksurfaces To  
Adjustable Height Columns

## Adjustable U-Unit Assembly (continued)




**Notice To Installers:** Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.

**Step 6****Fasten Bridge To Main Worksurface**


- Push worksurfaces together so all surfaces and edges are tight and flush to one another

**Adjustable U-Unit Assembly (continued)**


- While worksurfaces are being held firmly together, fasten brackets to under side to adjustment column using four (4) #8 X 7/8" flat head screws per bracket.

**Step 7****Attach Modesty Panel (Optional)**


- Fasten Modesty Panel to Worksurface using #8 X 7/8" flat head screws



Leave 1/8" gap between front panels and modesty panel. Using a 1/8" spacer is recommended.



**Notice To Installers:** Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.



**Step 8****Attach Wire Manager  
(Optional)****Adjustable U-Unit Assembly  
(continued)**

**Notice To Installers:** Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.





**Step 9**

Route Power Cord  
Through Wire Manager

**Adjustable U-Unit Assembly  
(continued)**

**Notice To Installers:** Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.

**Step 10****Attach Credenza****Adjustable U-Unit Assembly  
(continued)**

**Notice To Installers:** Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.