


# FLUX OPEN PLAN

## HOW TO ATTACH A WIRE MANAGEMENT BASKET

### Recommended Tools



### Hardware Needed



1/4-20 x 1/2" PHP  
Machine Screws

Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.

1. Attach the power source to the main aluminum rail so that it is centered using the screws provided. Screws will go through pre-attached tabs and into the grooves of the rail (Figure 1)
2. Secure the wire management basket stems using 1/4-20 x 1/2" machine screws (Stems 17" center to center). The screws will go through the stems and into the grooves of the aluminum rail.
3. Turn the stems to slide the basket into place, then rotate them back when basket is correctly positioned

