


FLUX OPEN PLAN

INSTALLATION AND ASSEMBLY OF SLAT WALLS WITH ACCESSORIES

Recommended Tools



Hardware Needed



#8 x 3/4" PHP Screws

Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.




Figure 1

1. Remove the peel strip from the face of the rubber bumper provided, then place the bumper on the bottom of the slat wall tabs (Figure 1)
2. Slide the slat wall onto the worksurface in the desired location (Figure 2)
3. Secure the wall by screwing #8 x 3/4" screws into the pre-drilled holes on the bottom of the slat wall (Figure 3)




Figure 2




Figure 3

FLUX OPEN PLAN

INSTALLATION AND ASSEMBLY OF SLAT WALLS WITH ACCESSORIES

1. Slide tabs on the end of the accessory being attached into the slot on the wall (Figure 1)
2. Let the accessory rest on the wall (Figure 2)

Figure 1




Figure 2

