



## Attaching Leg Base to Credenzas and Storage Cabinets

## Recommended Tools



## Leg Base Assembly on Credenzas &amp; Pedestals




## Hardware Used


 #8 x 3/4" Pan Head Wood Screws

**Step 1****Leg Base Installation**

- Flip cabinet upside down and lay on flat clean and debris free pad.
- Turn leg base upside down and place on the bottom of the cabinet.
- Measure front to back and side to side to assure the base is centered on the cabinet. Mark with a pencil the position of each hole on the mounting plates and tabs.
- Fasten leg base to the bottom of the cabinet using #8 x 3/4" pan head screws.

**Step 2**

- Carefully flip the cabinet upright and into place.
- Level cabinet front to back and side to side by rotating adjustable glides.



**Notice To Installers:** Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.