


FLUX OPEN PLAN

HOW TO ATTACH A PRIVACY HOOD



1. Attach the peel and stick plastic washer to the bottom face of the mount on the hood (Figure 1)
2. Tighten the set screw located on the bottom of the mount against the bottom of the worksurface to secure the hood (Figure 2)




Figure 1




Figure 2

Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.