


# FLUX OPEN PLAN

## HOW TO ASSEMBLE A RUNOFF RETURN WORKSURFACE

### Recommended Tools




### Hardware Needed





#10 x 7/8 PHP Screws


Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.

## Assembly With Privacy Panels



1. Lay privacy panel down on a nonmarring surface
2. Attach worksurface using L brackets and the #10 x 7/8 screws provided. Outermost brackets on both privacy panels should be approximately 3 inches from the edge. One bracket should be centered on each privacy panel. The center of the worksurface should be 28 inches from the bottom of the privacy panels (Figure 1)
3. Gang the return to the desk using the flat brackets and #10 x 7/8" screws provided. The outermost brackets should be approximately 2 inches from sides and the center bracket should be centered horizontally (Figure 2)






## Assembly Without Privacy Panels

# FLUX OPEN PLAN

## HOW TO ASSEMBLE A RUNOFF RETURN WORKSURFACE

### Recommended Tools



### Hardware Needed





#10 x 7/8 PHP Screws



1/4-20 x 1/2" PHP Machine Screws

Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.



1. Attach the metal stretcher to the end support using the 1/4-20 x 1/2" screws provided (Figure 1)
2. Attach the top to the stretcher and end support using the #10 x 7/8" screws provided using the pre-attached metal tabs with #10 x 7/8" screws so that it is centered side to side and flush with the end support frame (Figure 2)
3. Connect the frame to the existing desk so that the top is butted against the main worksurface using #10 x 7/8" screws and the pre-attached metal tabs (Figure 3)
4. Attach the flat brackets for the bottom of the tops so that they are 2 inches from the sides of the new top using #10 x 7/8" screws (Figure 4)

