





Mounting of Peninsula Desks w/End Leg/Post Frame to Support Credenza

Recommended Tools




Installers: To properly install the Flux Peninsula Desk product you will need a floor plan to assure proper installation. Peninsula Desk require a secondary height credenza with factory installed mounting.

Hardware Used



Step 1 Attaching Top Support Rail

- Unpack the end leg assembly/post frame assembly along with the hardware.
- Align the top support rail perpendicular to the end leg assembly/post frame assembly using the two 1/4-20 pan head bolts to secure the top.




Notice To Installers: Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.

Mounting of Peninsula Desks with End Leg/Post Frame *continued*


Step 2 End Frame Assembly / Post Frame Assembly Installation

- Flip worksurface top upside down and lay on a flat clean debris free pad.
- Place leg or post assembly onto the bottom side of the worksurface top.
- Align the leg or post assembly with the prebore holes on the top. (*tabs on Top Support Rail are not pre-bored*)
- Fasten assembly to the bottom side of the top using #8 x 7/8" pan head screws.




Step 3 Review the Layout

- The product offers two different locations to mount the peninsula desk to the secondary height credenza. The layout plan should indicate the correct mounting location. Guide lines in this step will explain the flush mount location or the offset mount location.



Flush Mount Location **A**
back panel of top support flush
with back panel of credenza




Offset Mount Location **B**
back panel of top support inset
5" from back panel of credenza

Notice To Installers: Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.


Mounting Peninsula Desks with End Leg/Post Frame *continued*

Step 3 *continued* Review the Layout for Mounting Location


• Layout with an overhead cabinet requires the offset mounting location. If using the wall panels the offset location mounting location is also recommended.



layouts with overhead cabinets require offset mount location




layouts with wall mount items, recommend using offset mount location



offset mount locations increases overall layout footprint by approximately 5"

Step 4 Mounting the Peninsula Desk (Note: Prior to performing Step 4 check for options see next page for Option A and or B)



Step 4 Mounting the Peninsula Desk

- Align the correct mounting holes on the “double” T support with the holes on the credenza top
 - position = flush mount location **A**
 - position = offset mount location **B**
- Fasten peninsula desk from inside the cabinet using $\frac{5}{16}$ " x $1\frac{1}{2}$ " hex head bolts with washer into the the bottom of the “double” T support.
- Finish by leveling the produc using the adjustable glides located on the end leg assembly or the post frame assembly.

Notice To Installers: Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.