

FORGE CORNER FILLER & CORNER WORKSURFACE

Install Instructions

Tools Required

- Pencil
- Tape Measure
- Level (Small and Large)
- Small Crow Bar
- Drill
- Drill Bit Sets and Screw Sets

Separately Specified Hardware

- 4 - Flat Brackets (GPFBRKT)
- 1 - L-Bracket (GPLBRKT20)

- 4 - 5/8" Screws (per cabinet)
- 12 - 5/8" Screws (per filler)

Installer Provided Hardware

- It is the responsibility of the installer and/or contractor to select and install the proper fasteners in the structural wall.

Installation

1. Remove Cabinet doors and drawers.
2. Create a level reference point for the cabinets using a Laser Level. Set the line 2" above the preferred height of the cabinets (Figure A).
Standard heights are 32-1/2" and 35".
Tip : Always measure from the high point on the floor.
3. Attach the Corner Filler to the first cabinet using the provided L-Brackets. Make sure the Filler is flush with the front of the End Panel (Figure B).

Figure A





Figure B



FORGE FORGE CORNER FILLER & CORNER WORKSURFACE

Install Instructions

- (1) Place both cabinets against the wall and line up the Corner Filler with the second cabinet. Make sure the Corner Filler is flush with the front of the End Panel of the second cabinet. (2) Level the cabinets using the Laser Line, measuring down 2". (3) Attach the Corner Filler to the Second Cabinet. (4) Attach the cabinets to the wall (Figure C).
- Attach the Worksurface Support L-Bracket to the wall measuring down 2" from the Laser Line. Anchor the L-Bracket to the wall using the Substructure and/or Toggle Anchors (Figure D).
- Place the Corner Worksurface on the cabinets and the Support L-Bracket. The Support L-Bracket will not attach to the Work Surface. The Cabinet L-Brackets will be used to anchor the Worksurface (Figure E).

Figure C




Figure E





Figure D



FORGE FORGE CORNER FILLER & CORNER WORKSURFACE

Install Instructions

7. Attach the Corner Worksurface to the cabinets using the 4 small L-Brackets in the cabinets and 5/8" screws (Figure F).
8. Attach 4 Flat Brackets to the Corner Worksurface using 5/8" screws. The remaining worksurfaces will attach to the Corner Worksurface using the Flat Brackets (Figure G).
9. Place the remaining Worksurfaces on the cabinets attaching them to the Flat Brackets and Cabinet L-Brackets using 5/8" screws (Figure H).
10. Re-attach Cabinet Doors and Drawers.

Figure F




Figure H




Figure G

