

WORKSURFACE BRACKET

Install Instructions

Tools Required

- Pencil
- Tape Measure
- Laser Level
- Level (Small and Large)
- Drill
- Drill Bit Sets and Screw Sets

Hardware Included

- 3 - 3/4" Screws

Installation

1. Set a laser line on the top edge of the cabinet. Mark the wall substructure along the laser line where the bracket will attach. Bracket must attach to the substructure (Figure A).

Note: Placement of the bracket must not be inset more than 8" from the edge of the worksurface (Figure C).

2. Place the bracket on the wall and line it up with the laser line and the substructure. Attach the bracket to the wall fastening it to the substructure (Figure B).

Note: It is the responsibility of the installer and/or contractor to select and install the proper fasteners in the structural wall.

3. Attach the worksurface to the bracket using 3/4" screws (Figure C).

Figure A




Figure B




Figure C

