


LOK TRAINING TABLES



Assembly Instruction for Fixed Laminate Modesty Panel

Recommended tools



#2 Phillips Head



1/8" Drill Bit



Measuring Tape

1. Align metal angle brackets with the pre-drilled pilot holes on the back of the modesty panel (Fig.1A)
2. Attach each bracket with (2) #8x5/8" panhead screws provided (Fig 1B). Panels for tables 60" and longer require (3) brackets. Panels for tables less than 60" require (2) brackets.
3. Position the modesty panel on the underside of the table top. The modesty panel should be centered side to side (see diagram B). The face of the panel should be 3/16" from the approach edge of the table top. (see diagram A)
4. Mark the screw hole locations on the underside of the worksurface. Drill a 1/8" dia. x 1/2" deep pilot hole in the positions marked.
5. Align the brackets with the pilot holes and secure in place with (2) # 8x5/8" panhead screws provided.

Hardware enclosed



#8 x 5/8" Phillips
Panhead Wood
Screws

Qty= 12 for ≥60"

Qty = 8 for ≤48"



Metal Angle
Brackets

Qty= 3 for ≥60"

Qty=2 for ≤48"

NOTE: all screws provided must be installed for proper installation and compliance with product warranty.





Diagram A

