


# LOK TRAINING TABLES

## Assembly Instruction for Hinged Laminate Modesty Panel



### Recommended tools



#2 Phillips Head



1/8" Drill Bit



Measuring Tape

1. Align metal hinge brackets with the pre-drilled pilot holes on the back of the modesty panel (Fig.1A)
2. Attach each bracket with (2) #8x5/8" panhead screws provided (Fig 1B). Panels for tables 60" and longer require (3) brackets. Panels for tables less than 60" require (2) brackets.

### Hardware enclosed



#8 x 5/8"  
Panhead Screws  
Qty= 12 for ≥60"  
Qty = 8 for ≤48"



Hinged  
Brackets  
Qty= 3 for ≥60"  
Qty=2 for ≤48"

**NOTE: all screws provided must be installed for proper installation and compliance with product warranty.**





Fig. 1A



Back side shown

Fig. 1B

# LOK TRAINING TABLES

## Assembly Instruction for Hinged Laminate Modesty Panel (Cont.)





Diagram A

3. Position the modesty panel on the underside of the work surface. The modesty panel should be centered side to side (see diagram B). The face of the panel should be 3/16" from the approach edge of the work surface. (see diagram A)
4. Mark the screw hole locations on the underside of the worksurface. Drill a 1/8" dia. x 1/2" deep pilot hole in the positions marked.
5. Align the brackets with the pilot holes and secure each bracket in place with (2) # 8x5/8" panhead screws provided.




Diagram B