


LOK TRAINING TABLES

Assembly Instruction for Fixed Cantilever Base on Crescent Top

Recommended tools



#3 Phillips Head



1/8" Drill Bit



Measuring Tape

Hardware enclosed



#12 x 1" Phillips
Panhead Wood
Screws
Qty= 16



Set of (2) Bases

NOTE: all screws provided must be installed for proper installation and compliance with product warranty.





Fig-A

1. Place work surface bottom side up on a non-marring surface
2. Place the table legs on the work surface and align the front holes of the mounting plate with the appropriate pilot holes in the work surface (see Fig-A).
3. Mark the remaining hole locations for each base. Drill pilot holes 1/8"Ø x 1/2" deep in screw hole locations marked.
4. Align the leg mounting plate with the holes and secure in place with #12x1" panhead screws. Install (8) screws per leg. (see Fig-B)




Fig-B