


# LOK TRAINING TABLES

## Assembly Instruction for Fixed Cantilever Base on Lecture Top

### Recommended tools



### Hardware enclosed



#12 x 1" Phillips  
Panhead Wood  
Screws  
Qty= 16



Set of (2) Bases

**NOTE: all screws provided must be installed for proper installation and compliance with product warranty.**




Fig-A

1. Place work surface bottom side up on a non-marring surface
2. Place the table legs on the work surface and align the front holes of the mounting plate with the appropriate pilot holes in the work surface(see Fig-A).
3. Mark the remaining hole locations for each base. Drill pilot holes 1/8"Ø x 1/2"deep in screw locations marked.
4. Align the leg mounting plate with the holes and secure in place with #12x1" panhead screws. Install (8) screws per leg. (see Fig-B)





Fig-B