


LOK TRAINING TABLES

Assembly Instruction for Fixed T-Base on 120-degree Top

Recommended tools




#3 Phillips Head

Hardware enclosed



#12 x 1" Phillips
Panhead Wood
Screws
Qty= 24



Set of (3) Bases

NOTE: all screws provided must be installed for proper installation and compliance with product warranty.




Fig-A

1. Place work surface bottom side up on a non-marring surface
2. Place the table legs on the work surface and align the holes in the leg mounting plates with the pilot holes in the table top (see Fig-A).
3. Secure in place with #12x1" panhead screws. Install (8) screws per leg. (see Fig-B)





Fig-B