

VISION MODULAR

INSTALLATION OF A STANDARD HEIGHT MODULAR GANGING




Figure 1





Figure 2

Recommended Tools



#2 Phillips Head



Tape measurer

1. Position the two units being ganged so that they are flush on all sides (Figure 1)
2. Place a U-bracket near the front of the units so that it is encasing both end panels. Secure the bracket so that it is mated near the front stretcher. (Figure 2)
3. Position another U-bracket 2" from the back of the units so that it is encasing both end panels. Secure the bracket with the #8 x 5/8" PHP Screws (Figure 3)

Hardware Needed



U-Bracket



#8 X 5/8" PHP Screws
(Qty Varies)

Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.




Figure 3